

1. Cut 4 small pieces of cardboard (approximately 5cm square)
2. In the center of each piece, make a small hole that is just big enough for the temperature probe.
3. Make a hole in the solar cooker in the position shown. Distances are in cm.
4. Apply white glue to one side of each piece and the cooker.
5. Thread the pieces onto the probe.
6. Insert the probe into the cooker as shown.
7. Temporarily secure the cardboard by applying a small amount of hot glue to the outside of the assembly.
8. Allow white glue to dry.

